



B&W Turnoverball™ Gooseneck Hitch

A hitch when you need it ...
a level bed when you don't.

The Turnoverball is manufactured in the U.S.A. and installs underneath the bed of your truck. No welding required since it bolts directly to your trucks frame. Only a 4" hole in the bed is required and there is no need to remove the bed.

No wonder it's the #1 selling gooseneck hitch in America.



Remove Ball



Turn Ball Over



Replace Ball In Socket



GTW: 30,000 LB.
VTW: 7,500 LB.
Do not exceed
vehicle tow ratings.

4" extender
available





B&W Companion™ Fifth Wheel Hitch

Ever use your truck when you're not towing?
We thought you did!

It easily converts to a level bed.

- Remove coupler head.
- Remove mounting post from receiver.
- You're ready to tow!



Remove Coupler



Remove Base



GTW: 18,000 LB.

VTW: 4,500 LB.

Do not exceed vehicle tow ratings.



Replace Ball In Socket